




**Digital Cylinder (Z4)
HZ, HZ DK/MR**

ZS40.990536
23.08.2021


DE Kurzanleitung
EN Quick guide
FR Guide abrégé
NL Korte handleiding
IT Guida breve
DK Korte vejledning
SE Snabbguide





3 Variants













5 Installing the HZ cylinder









6 Installing the HZ DK cylinder












7.1 Battery replacement (active cylinder)












7.2 Battery replacement (passive/hybrid cylinder)













10 EU/UK Declaration of conformity



11 Help and other information



11. Help and other information



6. Montage HZ DK

